

Lab 5: Time Demux

Using Multiple OpCodes in RCC Workers

Objectives

- Learn how [RCC] Workers can:
 - Use different Protocols on different Ports
 - Nonstandard input:output port ratio (1:2 vs. 1:1)
 - Process incoming data based on message type (OpCode)
 - I/Q Data with Timestamps
- Reiterate:
 - C++ conventions
 - Accessing Port data and Properties
 - Framework interactions
 - RCC_ADVANCE vs. RCC_OK





Overview

- The "Time Demux" component receives I/Q sample data that has time stamps interleaved within it. This component recovers the original data stream and writes it out while also providing a second stream containing only the timestamps.
- Having data separated allows additional processing by tools expecting "just data," e.g. plotting an FFT





Application Worker Development Flow

- 1. Protocol (OPS): Create new or select pre-existing
- 2. Component (OCS): Create new or select pre-existing
- 3. Create new App Worker (Modify OWD, Makefile, and source RCC/HDL code)
- 4. Build the App Worker for target device(s)
- 5. Create Unit Test (<component>-test.xml, generate, verify and view scripts)
- 6. Build Unit Test
- 7. Run Unit Test

Step 1: Protocol



- Review the component's datasheet and familiarize yourself with the two protocols the component will be using:
 - The incoming *combined* (in-band timestamp) data format is described in iqstream_with_sync_protocol.xml, found in <Core Project>/specs.
 - The outgoing *data* format is described in iqstream_protocol.xml, found in <Core Project>/specs.
 - The outgoing time format is also iqstream_with_sync.

Step 2: Component

 Create the Component Specfile (OCS) based on the datasheet's Properties and Ports

Notables:

- Volatile flags on all status Properties
- Most attributes don't need to be set if "False"
- Output ports are *Producers*





Step 3: Worker

- - Open **₩CPI**

- Create an RCC Worker (OWD) based on the OCS
 - This lab will use C++
 - Enable the "start" ControlOperations
- Test the build with the "empty" worker using IDE
 - You should be familiar at this point
 - What to expect:
 - Linking final artifact file <X> and adding metadata to it...

Step 3 (cont.)

- Copy time_demux.cc from /home/training/provided/lab5 over your skeleton
- Fill in the logic, noting (read the next slide too):
 - gen/time_demux-worker.hh exposes a lot of information, including enums
 - C++ data access
 - Sequences: <PortName>.<OpName>().<ArgName>().data() and .size()
 - Scalars: <PortName>.<OpName>().<ArgName>()
 - On output ports:
 - <PortName>.<OpName>().<ArgName>().resize() counts data elements
 - setLength()/setDefaultLength() tell show much to send in bytes
 - setOpCode()/setDefaultOpCode() set the opcode
 - Use RCC OK, not RCC ADVANCE
 - manually advance() ports if/when used





Step 3 (cont.) - Additional Hints

Open

- A helper function like increment counters is useful
 - Isolates Messages_Read and Bytes_Read Properties' logic
- Example start() method guarantees only *Time* opcode is ever sent
- Search for "???"
- Cannot directly copy I/Q Data structures across different protocols!
- *Most* C++11 constructs can be used by adding to Worker-level Makefile:
 - RccExtraCompileOptionsCC centos6=--std=c++0x
 - RccExtraCompileOptionsCC centos7=--std=c++11
 - RccExtraCompileOptionsCC_xilinx13_3=--std=c++11

Step 4: Build Worker

• Build the Worker for the host and Matchstiq (using IDE)





Step 5: Create Unit Test

 Copy "time_demux.test" into components library of your training project from the

"/home/training/provided/lab5/" directory

Step 6: Build Unit Test

- Build the test
 - (Use standard test procedures as in other labs)





Step 7: Run Unit Test on the Host

Open

- Run the tests
- Property values are not verified
 - Can be found in run/centos7/case00.00.time_demux.rcc.propsfile_read
 - Manually verify that UUT's messages and bytes read match file_read's
 - Did you count timestamps as a single 64-bit payload?
 - Current_Second should be close to

start time + bytes read \div (samples per second \times 4)

Step 7b: Run Unit Test on Matchstiq-Z1

• (Use standard test procedures as in other labs)



